



# EVO Scorpion Stock Adapter

## Installation instructions:

This procedure requires average skills. Read instructions completely before proceeding. In general the procedure is to remove the rear cover and slide on the stock adapter.

## NOTE:

**This stock adapter is designed to be a tight fit to the receiver and may require more effort to install and remove than the original rear cover. This is to insure that there is no movement or wobble of the stock, once installed**

## Tools and Materials:

5/32" diameter punch or dowel to depress rear cover button  
(Optional) rubber mallet or soft faced hammer

## Procedure:

- 1) Point firearm in a safe direction, remove magazine and insure firearm is unloaded.
- 2) Insert 5/32" diameter punch or dowel into rear of rear cover and depress button. While depressing button, push rear cover up from bottom and slide off of rear of receiver. If rear cover is difficult to move, lightly tap with rubber mallet or soft faced hammer.
- 3) From top of gun, slide stock adapter onto rear of gun. When the stock adapter gets close to the button, depress button so stock adapter can slide over it. Continue to push adapter until it fully seats. If necessary, use rubber mallet or soft faced hammer to lightly tap into place.