

M-11/9, M-11A1 and M-10/45 2-Piece Grip

Installation instructions:

This procedure requires average skills. Read instructions completely before proceeding. In general the procedure is to remove the grip from the grip housing, and reassemble using the new 2-piece grip.

Tools and materials:

Flat Head Screwdriver

Procedure:

- 1) Point firearm in a safe direction, remove magazine and insure firearm is unloaded and not cocked.
- 2) Using a flat head screwdriver, remove backstrap retaining screw from back of grip. Remove grip backstrap.
- 5) Place lower receiver upside down with magazine housing pointing up.
- 6) Carefully spread open grip body just enough to allow it to slide over magazine housing end.
- 7) Slide grip body over magazine housing end and push up until it is flush with bottom of receiver.
- 8) Take the flat head backstrap screw and apply thread locker to it. (Loctite Threadlocker 242 recommended)
- 9) Place grip backstrap onto back of magazine housing and insert backstrap screw through mounting hole in backstrap.
- 10) Lightly tighten screw. Leaving enough room for the front grip portion to move.
- 11) Squeeze the front grip portion that will be secured by the backstrap. Ensure front grip and backstrap are aligned flush on both sides.
- 12) Using a flat head screwdriver, tighten grip retaining screw through back of grip. Do not overtighten the grip retaining screw or you will risk shearing the plastic in the backstrap.