



GRIP PLUG TYPE 2 INSTRUCTIONS

1. Insert Grip Plug into mag well until it latches.
2. Follow instructions for latching the IRM latch included in the manual for your specific Upper.
3. Instead of a magazine, gently push the button on the bottom of the plug to engage the IRM latch.

NOTE:

Do not press the button while cocking the bolt to the rear position.

This may damage your IRM Latch. Please follow the latching instructions provided in the manual.



GRIP PLUG TYPE 2 INSTRUCTIONS

1. Insert Grip Plug into mag well until it latches.
2. Follow instructions for latching the IRM latch included in the manual for your specific Upper.
3. Instead of a magazine, gently push the button on the bottom of the plug to engage the IRM latch.

NOTE:

Do not press the button while cocking the bolt to the rear position.

This may damage your IRM Latch. Please follow the latching instructions provided in the manual.



GRIP PLUG TYPE 2 INSTRUCTIONS

1. Insert Grip Plug into mag well until it latches.
2. Follow instructions for latching the IRM latch included in the manual for your specific Upper.
3. Instead of a magazine, gently push the button on the bottom of the plug to engage the IRM latch.

NOTE:

Do not press the button while cocking the bolt to the rear position.

This may damage your IRM Latch. Please follow the latching instructions provided in the manual.